

# Pressure and injector blast cabinets



Symbol	Consequences	Probability
🛕 Danger	Death or serious injury, irreversible	Will result
Warning	Death or serious injury, irreversible	Could result
	Minor or moderate injury, reversible	May result
Caution	Property damage	May result

Revision: 6

# 0.1 General advise

This owner's manual is:

-Is part of the product -must be retained near to the product throughout the product's service life -must be handed over to any subsequent owners.

Design and owner manual were developed based on a risk analysis. That means that:

+ the machine or blast cabinet must not be changed,

+ the operator/user must be trained.

All wearing parts are without guarantee.

### 0.2 Training of operating personnel

The operating personnel used to operate the machine or system must be well trained and well informed about the hazards associated with the process.

# 0.3 CE- conformity

Refers to a complete blast cabinet, that means. cabinet, cyclone (option), hoses, filter with fan and the pneumatic and electric controls. If only components are purchased, the CE conformity only applies to these.

Conformity is based on a risk assessment according to the Machinery Directive 2006/42/EG and the associated regulations.

### 0.4 Explosion protection - organizational measures

The system does not fall under the scope of Directive 2014/34/EU (ATEX 95) and is therefore not approved for operation in an explosive atmosphere.

Explosive dust mixtures (zones) can form inside the system that must not be carried outside. For this purpose, the following requirements in particular must be met by the operator:

- For maintenance, cleaning and repair work

- -the system must be depressurized and de-energized.
  - -no sparking work (grinding, welding, cutting work, etc.) may be carried out in the presence of dust within a radius of 3m

-the regulations (operating manual) must be observed when emptying the dust container and changing cartridges.

- Dust deposits in the vicinity of the blasting system and filter system must be removed immediately. Criteria for dust deposits to be removed are recognizable footsteps and/or surface colors of the substrate that are no longer recognizable.

- The maintenance and operating personnel must be trained in relation to fire and explosion hazards.

### 0.5 Applications and restrictions

The blasting cabin is designed to be operated by one person only.

#### Table 1: Permissible applications

Parameter	Value / requirements			
Transport temperature	20°C to +70°C			
Operating area	Only in closed rooms, not in aggressive or areas / atmospheres at risk of explosion			
Steadiness	Even, solid ground - Superstructural parts (e.g., silos) require additional arrangements for sufficient steadiness			
Grounding	Cabinet must be grounded, otherwise there is danger of explosion or electrostatic shocks Each cabinet has a central grounding point that is well marked for the user.			
Working conditions	Closed working room, temperature: 15–30°C, relative humidity: < 85%			
Compressed air supply:				
Medium	Filtered, oil-free and dried compressed air according to ISO 8573-1, Class 6-4-4, free from aggressive components			
Operating pressure:	2–7 bar. A pressure reducer and a safety valve have to be installed in the service pipe if there is a higher pressure in the air supply.			
Requiredon site	Shut-off valve for compressed air			
Abrasives	<ul> <li>-Processable / conveyable abrasives in the suction process: see Table 2,</li> <li>-From the point of view of explosion hazard: see section 0.6</li> <li>- Concentrations of hazardous substances in blasting media which must not be exceeded - see Table 3</li> </ul>			

#### Table 2: Processable abrasives

Abrasives		Grit (µm)	Remarks
Metallic	Round forms	30 400 µm (40 mesh)	Suction hose "cabinet - cyclone" 25mm smaller than stan-
	Edged forms	30 600	dard hose
Mineral	Sand and Scum		Not recommended due to short service life
	Corrundum	70800	Use additional wear protection
	Glass beads	70800	Very dry air required
Organic	Plastic	100 1600	

#### Table 3: Maximum concentration of hazardous substances in blasting media

The following concentrations of hazardous substances in blasting media must not be exceeded:

Identification of the hazardous substance	Information
Antimony, Lead, Cadmium, Tin, Arsenic, Berylium, Chromate, Cobalt Nickel	Total : 2% by weight
Arsenic, Berylium, Chromates, Cobalt and Nickel	Total: 0.2% by weight
Berylium, Chromates, Cobalt, Cadmium	Each 0.1 percent by weight
Metallic Compounds	Are to be calculated as CrO3 like metals and chromates
Free crystalline silica (SiO2)	2 percent by weight

# 0.6 Defined zones inside Clemco's standard blasting cabinets according to dust concentrations and the blasting media / object blasted combinations

	Blasting media type	Blasting process	Grain size	e Remarks	Permissible blasting objects	Blasting p	orocess	I	Remarks
a	Light metals	Inj. + pressure	All	Only permitt	ed Light metals	lnj. + pre	essure	Only permissible w	ith mineral blasting media!
b	Organic	lnj. + pressure	All	after in-house assessment l customer	2	lnj. + pre	essure		tted after in-house ment by customer
с	Mineral	Injector	≥ 20 to 800 µ	um	Mineral	Inject	or	Only permissible w	vith mineral blasting media!
		Pressure	≥ 20 µm			Press	ure		
d	Ferritic, round	Injector	≥ 200 to 400		Ferritic, round and angular	Inject	or		nozzle, at 500 m³/h throughput
		Pressure	> 200 to 1250		(also stainless steel)	Press	ure	Max. Ø6.5 mm blasting	nozzle, at 500 m³/h throughput
e	Ferritic, angular	Injector	$\geq$ 200 to 600						
		Pressure	> 200 to 1250						
		<u>r Explosion view</u> ested combinations			se 2 as per Explosion view nissible, tested combinations			<u>Case 3 as per E</u>	<u>xplosion view</u>
	Total construct	tion inside - no zone		Blasting Cha	amber and Cyclone inside - no zone		investigat th	ion that the risk of explosic e zones can be prevented f Downgrading to case 2	en in the course of an individual on is sufficiently restricted or th rom being carried over <b>→</b>
F	Blasting media type	Blasted of	oject	Blasting media type	Blasted object		Bl	asting media type	Blasted object
	Mineral	Ferritie		Mineral	Paint-layer inertization not secured			Organic	Aluminum, ferritic
	Mineral	Minera		Mineral	Aluminum			Light metals	Light metals, ferritic
				Ferritic > $200 \mu m$	Ferritic				-
				Ferritic > 200 μm Ferritic > 200 μm	Paint layers Mineral				
			<b>1</b>	() () () () () () () () () () () () () (					
	Z	No zone Zone 22 Zone 21			No zone Zone 22 Zone 21			No zo Zone Zone	22

Zone 20

# 0.7 Stocking / limits

Parts/assemblies made of organic material are subject to natural aging, which depends on, among other things: (see table 4 +5).

Influences	Comments regarding long-term stocking
Temperature	Ideally between -10°C and +15°C, in any case the material should not be exposed to any heat source.
Ambient atmosphere	<ul> <li>-No ozone → no operation of electric motors, welding equipment, etc. in the storage room because they generate ozone.</li> <li>-No aggressive chemicals, e.g. solvents</li> </ul>
Humidity	- Humidity above 65% can lead to changes in the material.
Radiation influences	-Avoid direct sunlight and other UV sources.

# Table 4: Storage requirements

#### Table 5: Components with limited storage periods/service life

	Specified by	Total time of usage *1) Stocking + operation *2)	Usage in blasting unit *2)
Jet and air hoses	DIN 20066	max. 6 years	max. 6 years
Remote control hoses	DIN 20066	max. 6 years	max. 6 years
Pop-up valve (blast machine)	Manufacturer	max. 10 years	max. 5 years
O-Rings	Manufacturer	max. 10 years	max. 5 years
Gaskets	Clemco's experience	max. 10 years	max. 5 years

\*1) The service life can be greatly reduced at temperatures < 25°C, in the event of direct sunlight or other negative influences.</li>
 \*2) Mechanical wear due to operation is not taken into account.

### 0.8 Noise level

Depends on the blasting pressure, number of nozzles, nozzle diameter, geometry of the blasting material, type of blasting agent, etc. It is normally between 80 and 120dB(A) without additional noise protection measures. Noise impairments: >  $80dB(A) \rightarrow Ear$  protection must be worn.

### 0.9 Dust exposure: $< 1mg / m3 \Rightarrow$ Can only be guaranteed with proper maintenance.

Pay attention to: - Check the door seal and replace it if necessary.

- Empty the dust container at the prescribed intervals.
- Clean the cartridges or replace them.
- Dust off the blasted parts with an air nozzle, then leave the doors closed for at least 15 seconds.

### 0.10 Vibration level

The vibration value (emission value) to which the hand / arm system is exposed is less than 2.5 m/s<sup>2</sup>.

#### 0.11 Safety notice

-The blasting process stops when the foot pedal is released and a door is opened.

<u>Caution!</u> After the compressed air has been switched off, the blasting media escapes from the nozzle for a short time until the pressure in the blast pot has been reduced

- -Bursting of blasting machine parts due to wear compliance with the prescribed maintenance measures and monitoring intervals.
- -Generation of an explosion hazard due to the escape of dust → Compliance with the requirements of section 0.4.

#### 0.12 Air consumption of the blast nozzle

Select the compressor output at least 50% higher, because consumption increases with wear of the blast nozzle.

# Table 6: Injection blasting

Diameter[mm]		Nozzle number:	Air consuption [m <sup>3</sup> /min.] at a pressure of:		
Air bozzle	Blast nozzle		<u>3</u> [bar]	<u>5,5 [</u> bar]	<u>7 [</u> bar]
3,2	6,0	4	0,4	0,6	0,75
4,0	8,0	5	0,6	0,9	1,25
4,8	9,5	6	0,9	1,3	1,75
5,6	11,0	7	1,1	1,75	2,4

#### Table 7: Pressure blasting

Diameter blast nozzle [mm]	Nozzle number.:	Air consuption [m³/min.] at a pressure of:		
		<u>2,6 [</u> bar]	<u>4,9 [</u> bar]	<u>7</u> [bar]
3	2	0,3	0,4	0,6
4,5	3	0,6	0,9	1,3
6,0	4	1,2	1,7	2,3
8,0	5	1,8	2,8	3,7

# 0.13 Waste disposal

Туре	Disposal
Media disposal	Dependent on the blasted material
Filter cartridge	Dependent on the blasted material
Scrapping at the end of life	Disassembly of electrical parts → separate disposal